

# Mini Receiver Set-Up



## **Activating the Mini Receiver**

To turn the Mini receiver ON press the **Power Button** for 5 seconds, the LED will flash once, the receiver will beep and the Vibrator motor will vibrate to indicate the receiver is ON.

To turn OFF the Mini Receiver press the Power Button for 5 seconds, the LED will flash once to indicate the receiver is now back to sleep mode (OFF).

Low battery warning:

When the battery is low the receiver will flash the light and beep once, it will do this every few seconds until you replace the battery.

## **Programming the ATT Mini Receiver to the ATT car pager**

Turn the ATT Mini Receiver to ON then press and hold the **Program Button** for 5 seconds until the LED lights up, the Mini receiver is now in program mode. Activate your ATT Car Pager by opening a car door. The ATT Mini Receiver LED will turn off to indicate correct programming.

## **Activating/De-activating Beep Mode**

Turn the ATT Mini Receiver to ON then press the **Beep Mode Button** for 1 second, the LED will flash once indicating the sound-mode is OFF.

Press the Beep Mode Button for 2 seconds, the LED will flash once and the beeper will sound indicating sound-mode is now back on.

## **Activating/De-activating Vibrate Mode**

Turn the ATT Mini Receiver to ON then press the **Vibrate Mode Button** Button for 2 seconds, the LED will flash once indicating the vibration function is turned off.

Press the Vibrate Mode Button for 2 seconds, the LED will flash once and the vibration will activate indicating the vibration function is turned ON.